

Pouring Concrete at a Job Site

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Trips	Hard Hat	
Slips	Steel Toed Boots	
Falling Objects	High Vis Vest	

Safe Work Procedure:

- 1) Once you arrive at the job site get out of your mixer and survey where you need to go
- 2) Find the contractor/supervisor and discuss how they want the concrete to be poured, and where. They should also check the concrete and determine if they want any water added to the mix
- 3) Get back into your mixer and enter the jobsite. Add chutes if necessary and discharge concrete as per contractor/supervisors needs
- 4) Once you are empty, lock your chute in place and exit the mixer. Procedure to the back of the mixer and, using a shovel, scrape the concrete from the chute.
- 5) Give the contractor/supervisor the pink copy of your load ticket and then determine where you can wash out
- 6) Once in the mixer, use the radio to let dispatch know your situation. For example: If you are empty- tell him that you are empty etc.
- 7) Go to the washout area and follow the mixer washout (jobsite) procedure

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

Guidance Documents/Standards: MB Workplace Safety & Health Act & Regulations	This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years
	Reviewed By WSH Committee: Date: