

Stripping Forms

<b>Facility:</b>	<b>Written By:</b>	<b>Approved By:</b>	<b>Date Created:</b>	<b>Date of Last Revision</b>

<b><i>Hazards Present:</i></b>	<b><i>PPE or Devices Required:</i></b>	<b><i>Additional Training Required:</i></b>
Vehicle/Pedestrian traffic	Steel Toed Boots	
Contact with equipment	Gloves	
Pinch points	Safety Glasses	
Falling objects	Hard Hat (where applicable)	

**Safe Work Procedure:**

- 1) Park truck and trailer used for transporting materials close to the basement
- 2) Place ladders and ramps in position to access the inside of the basement
- 3) Remove the snap ties from the forms
- 4) Remove the wedges from the forms and load them onto the trailer
- 5) Using a hammer/pry bar, remove the forms
- 6) Load forms onto the trailer
- 7) Remove the lumber frames from around the base of the foundation and load them onto the trailer
- 8) Break off all remaining snap ties
- 9) Ensure load is secured before driving off the work site

***If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure***

**REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR**

<p><b>Guidance Documents/Standards:</b></p> <p>MB Workplace Safety &amp; Health Act &amp; Regulations:                      Part 6 Personal Protective Equipment                      Part 13 Entrances, Exits Stairways &amp; Ladders                      Part 30 Temporary Structures</p>	<p>This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years</p>
	<p>Reviewed By WSH Committee:</p> <p>Date:</p>