

Washing Out Concrete Truck (Jobsite)

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Trips	Hard Hat	
Slips	Steel Toed Boots	
Falling Objects	High Vis Vest	

Safe Work Procedure:

- 1) Once you are the washout site, exit the mixer and ensure your side water tank is pressurized
- 2) Unwrap your hose and proceed to wash mixer. Start with the chutes and proceed to the outside, then the inside of the drum and then the remainder of the mixer.
- 3) If you put chute extensions on, put them away and secure them with straps provided, then wrap up and secure your water hose, controller and shovel
- 4) Do one last visual inspection to ensure that you washed everything and all items are secured properly. If you are the last mixer on site, ensure to check with the contractor if they need anything else. Then depressurize your water tank
- 5) Get into your mixer and radio your status to the dispatcher and return to the plant.

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

Guidance Documents/Standards: MB Workplace Safety & Health Act & Regulations	This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years
	Reviewed By WSH Committee: Date: