

Adding AD-Mixtures on Job Site

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Trips	Hard Hat	
Slips	Steel Toed Boots	
Falling Objects	High Vis Vest	
	Gloves	
	Eye Protection	

Safe Work Procedure:

- 1) once on the job site communicate with the contractor that you have ADMIX to add to the load
- 2) Slump load to contractors specifications
- 3) Remove ADMIX from the cab of the mixer. Using three point contact, climb the ladder to the top of the mixer and, depending on the ADMIX, either add it directly to the concrete or simply dump it into the hopper
- 4) Climb down using three point contact, rev up your mixer and ensure the drum is spinning at full revolutions for a minimum of 70 revolutions
- 5) Show the contractor the concrete and add more water as per contactors instructions

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

Guidance Documents/Standards: MB Workplace Safety & Health Act & Regulations	This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years
	Reviewed By WSH Committee: Date: