

Pre-Trip Inspection – Concrete Truck

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Trips		
Slips		

Safe Work Procedure:

- 1) Approach mixer and undo latches and open mixer hood
- 2) Check oil and antifreeze levels
- 3) Do a general inspection under the hood including belts, suspension etc.
- 4) Enter the mixer and start engine
- 5) Exit the mixer taking the hammer that is in the mixer with you; check tires by hitting the tires and visually inspecting
- 6) Walk around and make sure to check all lights
- 7) Once at the back of the mixer use all the buttons on your controller to make sure that they are in working order. Ensure that the drum is rotating in discharge to ensure all water has been drained from the drum
- 8) Enter the mixer and turn off emergency lights. Ensure there is sufficient fuel and that the air pressure is at the right PSI
- 9) Take your place in line and once it's your turn, back under the sock to get loaded.

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

Guidance Documents/Standards: MB Workplace Safety & Health Act & Regulations	This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years
	Reviewed By WSH Committee: Date: