

Dismantling Oxy/Auto Equipment

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Inhalation of gas	Helmet	
Physical injury	Eye protection	
Potential for explosion	Gloves	
	Steel toe boots	

Safe Work Procedure:

- 1) Make sure both bottle tops oxy & auto are shut off
- 2) Open and close one valve at a time on torch handle to extinguish any remaining gas out of lines
- 3) Remove valve gauge cluster at a time from bottles & install tops on and remove gauge clusters
- 4) Release jacking mechanism from bottles on the cart
- 5) Load bottles into vehicle for transport
- 6) Do process in reverse for installing

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

<p>Guidance Documents/Standards:</p> <p>MB Workplace Safety & Health Act & Regulations:</p> <p>2.1 Eliminating or control of risks</p>	<p>This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years</p> <hr/> <p>Reviewed By WSH Committee:</p> <p>Date:</p>
---	---