

Inserting A Wire Into A Box

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Cuts	Eye Protection	Operator Manual
Fuel fire	Hand Protection	
Muscle strain	Steel Toed Boots	
Discharged objects	Hard Hat	

Safe Work Procedure:

- 1) Grab the skinned wire and push it through the opening of the box ensuring that about ¼ to ½ inch of insulated material is extended into the clamp
- 2) Ensure that there is six inches of skinned wire extending into the box
- 3) Tighten down the wire clamp
- 4) “Ground” the copper ground wire to the box

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

<p>Guidance Documents/Standards:</p> <p>MB Workplace Safety & Health Act & Regulations:</p>	<p>This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years</p>
	Reviewed By WSH Committee:
	Date: