

### SAFE WORK PRACTICE

<b>TITLE</b>	Concrete Cribbing
<b>GENERAL</b>	Protecting workers from injuries associated with prepping a work area for poured concrete.
<b>APPLICATION</b>	Concrete foundations are structural members and will be completed as per approved specifications
<b>PROTECTIVE MECHANISMS</b>	Personal Protective Equipment
<b>SELECTION AND USE</b>	Job requirement
<b>SUPERVISOR RESPONSIBILITY</b>	To facilitate and/or provide proper instruction to their workers on protection requirements
<b>WORKER RESPONSIBILITY</b>	<ol style="list-style-type: none"><li>1. Ensure the concrete forms are secured from movement.</li><li>2. Ensure you are conversant with concrete pour procedures.</li><li>3. Ensure you are visible to the crane operator placing framing in excavated area.</li><li>4. Use universal hand signals with crane operator and discuss signals to confirm communication.</li><li>5. Ensure equipment is in good working order.</li><li>6. Follow safe work practice for ladders when getting in and out of the excavated area.</li><li>7. Always wear hard hat when working with crane and with the risk of overhead hazards.</li></ol>

\* The information presented in this publication is intended for general use and may not apply to every circumstance. It is not a definitive guide to government regulations and does not relieve persons using this publication from their responsibilities under applicable legislation