

**SAFE WORK PRACTICE**

<b>TITLE</b>	Pipe Coating/Jeeping
<b>GENERAL</b>	Protecting workers from injuries associated with pipe coating and jeeping.
<b>APPLICATION</b>	The pipeline is coated and/or wrapped with special materials to prevent corrosion. Coating integrity is confirmed through detection of bare spots with special detectors (jeeps).
<b>PROTECTIVE MECHANISMS</b>	Safe work procedures WHMIS (MSDS) Manufacturer specifications Equipment maintenance procedures PPE Barricades and warning signs ERP (Emergency Response Plan)
<b>SELECTION AND USE</b>	As per safe work procedure Provincial OH&S Legislation
<b>SUPERVISOR RESPONSIBILITY</b>	Supervisors are responsible to facilitate and/or provide proper instruction to their workers on protection requirements and training Work site inspection Hazard Assessment
<b>WORKER RESPONSIBILITY</b>	<ol style="list-style-type: none"> <li>1. Regularly inspect equipment.</li> <li>2. Remain in operator's line of vision.</li> <li>3. Follow safe work procedures when jeeping.</li> <li>4. Use caution around moving equipment.</li> <li>5. Do not jump off equipment.</li> <li>6. Do not walk on the pipe</li> <li>7. Avoid inhaling coating fumes.</li> <li>8. Use PPE when coating or wrapping pipes.</li> <li>9. Follow pipe coating safe work procedures step by step.</li> </ol>
<p>* The information presented in this publication is intended for general use and may not apply to every circumstance. It is not a definitive guide to government regulations and does not relieve persons using this publication from their responsibilities under applicable legislation.</p>	